

Under Oil Arrester Disconnect Switch



The ECI arrester disconnect switch provides a means of performing electrical testing of distribution transformers that are equipped with internal under oil lightning arresters.

The arrester disconnect switch must be open before dielectric testing of the transformer to prevent misleading results and possible arrester damage.

To open the switch, unscrew the pipe plug, pull the plug out to the stop to disconnect the arrester ground. Reverse the procedure to close the switch.

This switch is for testing the transformer. It is a de-energized switch only.